



2024 Mustang Mach-E > Performance and Handling > Towing

Towing the Vehicle

Four-Wheel-Down Towing

- Four-wheel-down towing, also known as flat/neutral towing, refers to towing a vehicle with all four of its wheels on the ground – for example, when towing behind an RV (recreational towing)
 - Mustang Mach-E RWD/eAWD models **do not offer** four-wheel-down capability

Dolly Towing

- Dolly towing allows owners to tow their vehicle behind an RV or motorhome if they are unable to four-wheel-down tow their vehicle
 - Dolly towing works by letting the front two wheels of the vehicle rest on it while the back two wheels stay on the ground
 - Mustang Mach-E models **do not offer** dolly-tow capability
- If the vehicle becomes inoperable (without access to wheel dollies, car-hauling trailer or flatbed transport vehicle), it can be towed with all wheels on the ground (emergency tow), regardless of the powertrain and transmission configuration, under the following conditions:
 - The vehicle is facing forward for towing in a forward direction
 - Place the rotary gear shift dial in Neutral (N) and select "Emergency Tow" in the center-stack screen to prevent damage to the transmission. See Owner's Manual for detailed procedure
 - Maximum speed is 35 mph
 - Maximum distance is 50 miles
- Refer to the RV & Trailer Towing Guide and the vehicle Owner's Manual for complete details and restrictions

Vehicle	Four-Wheel-Down Capability	Dolly-Tow Capability		Recommended Emergency Towing
	Automatic	RWD	eAWD	
Mustang Mach-E	No	No	No	Flatbed equipment for all configurations

For availability of product features, please see Availability by Model and/or the [Dealer Ordering Guide](#).

© 2024 Ford Motor Company | Rights are granted to dealership personnel to download the contents of this web page in electronic or paper form. All other rights are reserved, including the rights to create derivative works and/or other web pages. Content is confidential and not to be posted on other sites or shared.