



Peterbilt 579EV  
Kenworth T680E

Model Year: 2022 – Current  
Release Date: 3/7/2022  
Part Number: Y53-6174-1B1



BEV badge are on all battery electric trucks on both sides of the cab.




### Extrication Diagram



650 V

#### E-PTO (Optional)



**Warning:** Check for labels identifying any additional High Voltage components added by body builders.

High Voltage Li-Ion Battery Pack	High Voltage Cables	12V Disconnect	Gas Strut
Charger Inlet (Forward or Rear)	High Voltage Region	Low Voltage Batteries	Lift Point
		Compressed Air Tank	

## 1. Identification / Recognition



**Warning:** Always wear full fire fighter PPE (turnout gear), including a positive pressure self-contained breathing apparatus, when approaching this vehicle.



OR



Battery electric truck badge on both sides of the hood

## 2. Immobilization / Stabilization / Lifting




**Warning:** Keep all lift equipment at least 12 inches (30 cm) from all high voltage components.




**Warning:** Vehicle noise may be reduced in some operation modes. Failure to shutdown the truck before immobilization could result in death, severe injury, or property damage.

**Complete Section 3 steps if possible before immobilization.**



Blocking Wheels

Block all wheels



Lifting Truck  
(with Jack)

Only use the lift points identified in the extrication diagram with this icon for jacks



Rotating Truck

Wrap chains around both axles to rotate the truck to an upright stable position

## 3. Disable Direct Hazards / Safety Regulations



**Warning:** Assume all high voltage components are always energized. Do not cut any High Voltage components, including high voltage orange cables.




**Warning:** Cables between the high voltage battery and the S-box remain energized even after the vehicle disable steps (including the 2-minute wait) are completed.



**Warning:** Call the PACCAR Customer Center for guidance 24/7 before proceeding if any high voltage part damage could have occurred.

**Peterbilt Phone #: 1-800-473-8372**

**Kenworth Phone #: 1-800-592-7747**



**Step 1:** Unplug the Charger Cable or Remove Power from the Charger




**Step 2:** Remove the Key from Ignition



**Step 3:** Engage park brake

**Step 4:** Unlatch hood and tilt hood forward



**Step 5: (Primary Step):** Turn 12V Disconnect Counterclockwise to OFF Position



**(Alternate Step):** Cut a 5-inch (13 cm) segment (2 cuts) from the black cut loop (identified in the Extrication Diagram)



**Step 6:** Wait 2 Minutes for High Voltage Capacitors to Discharge

## 5. Stored Energy / Liquids / Gases / Solids



High Voltage (650 V)



Corrosives



Flammable



Health Hazards

## 6. Fire

**Warning:** Always wear full fire fighter PPE (turnout gear), including a positive pressure self-contained breathing apparatus.

**Warning:** Treat fires involving charging stations as energized fires until power to the charger can be shut down.



**Use Water to Extinguish Li-ion Fires**



**Do Not Use Wet Foam**



**Hazardous to Human Health:**

- May cause an allergic skin reaction
- Do not breathe dust, fumes, gas, mist, vapors, or spray



**Flammable Components**



**Explosion Hazard:**

- Explosive gas could accumulate.
- Move truck outside building after extinguishing fire



**Corrosives:**

- Causes skin burns and eye damage



**High Voltage (650 V):**

- CAT III (1000 V) rated gloves required for exposed HV parts



**Check Li-ion Battery Pack for Fires with Thermal Infrared Camera (TIC or IR Gun)**

## 7. Water Submersion



- If High Voltage part damage exists (hissing, crackling, bubbles, exposed cables, etc.), call the PACCAR Customer Center for guidance (**1-800-473-8372**)
- If no High Voltage part damage exists; remove the truck from the water; let the water drain; follow Section 3 (Disable Direct Hazards); and do not attempt to drive

## 8. Towing / Transportation / Storage



- Follow Section 3 (Disable Direct Hazards).
- Use Lift Points in Section 2: Immobilization and the Extrication Diagram.
- Put the transmission in neutral to avoid damaging the eAxles.

### Towing Method

If high voltage components were damaged or submerged, transport the truck with all wheels on a trailer. Do not attempt to drive.  
If high voltage components were **NOT** damaged or submerged, use the cage bolts and remove the axle shafts to tow (propulsion motor not spinning).  
(Emergency) If the truck must be moved soon **AND** no high voltage damage exists, it can be moved at less than 25 mph for no more than 5 minutes.



- Store outdoors, 50 feet away from other equipment/structures, and routinely check the battery pack for high temperatures with a Thermal Imaging Camera (TIC or IR Gun).